

Ford Bronco 2021 automatic - RedlineGoods Shift Boot Instructions

Disclaimer: Redline Automotive Accessories Corp. (RedlineGoods) will not be held liable for any labor, incidental or consequential damages of any kind. Proceed at your own risk. Read the entire document before proceeding with your installation!

1. Grab the edges of the boot and feel the plastic frame that holds the boot in place. Pry it off by pushing in the center of each edge towards the shifter. A pry tool might help but is not necessary. **The picture shows the manual car but the pry points, and thus the explanation above and below fit the automatic!**
2. Lift the bottom of the boot, flip it inside out to locate the screw attaching the shift knob assembly to the shifter. It's located on the front of the shifter. Remove that screw to disconnect the boot and knob from the vehicle.



3. Examine the Shifter boot - it is mounted to a square plastic bracket.
4. Disconnect the shift boot from the shift knob – once you flip it inside-out, it will be obvious how they are attached.



5. Remove the original shift boot fabric from the plastic frame.
6. Install the RedlineGoods boot instead – glue it to the mounting frame. As for the glue – it’s nothing special, any good leather/upholstery glue you can find at a hardware store will do – just follow the instructions on the glue container and everything will work fine. We recommend a brush-on glue vs spray-on, and one that gives you some time to make adjustments while it cures, rather than an instant/super glue.
7. Replace everything in the reverse order of removal.



Congratulations – and enjoy your new Bronco shift boot from RedlineGoods!

Useful tip

Make sure to condition your new shift boot properly, using the proper care products for the material you’ve chosen for your shift boot (leather and Alcantara require different treatments) and you’ll enjoy it for years!